

HandPunch Network Configuration

Applies to models with the manufacturers' internal Ethernet adapter (HP50E, HP1000E, HP3000E, HP4000E)

Press **Enter** then **Clear** within Approximately 1 second

If a supervisor is enrolled, enter the supervisor's id number, press enter, place hand to verify.

When prompted for the password, type 2 and press enter.

Press NO(*) until you get to the Set Serial option, then press yes. (see important note at the bottom of the page)

The following items must be configured:

IP Address

Gateway Address

Host Bits

Baud

IP Address - Enter a unique IP address for the clock that is compatible with your network. Leading zeros must be entered in the clock, but not in the software. For example, 192.168.001.050 would be entered in the clock but 192.168.1.50 would be entered in the software.

Gateway Address - Enter the network gateway address, also using leading zeros. This is typically your router IP. Using the example IP address above, the gateway would usually be 192.168.001.001

Host Bits - This setting defines your network subnet mask. Typical networks, such as the examples above, have a 255.255.255.0 subnet mask. If this is correct for your network (or if you are unsure) then set the host bits to 8.

Baud - Leave as default (9600)

After all items are set, you will automatically return to Set Serial. Press clear to exit the supervisor area.

IMPORTANT NOTE *

The IP and Gateway address sections will time out if you enter the information too slowly. If it jumps ahead before you enter the correct information you will have to go through the rest of the settings and then enter the set serial section again.